
Receiver specifications

Supply Voltage: 100-240VAC 50/60Hz
Wireless protocol type: Tuya zigbee

- Radio Frequency Range: 2.4GHz
- Protection Level: IP21
- Shipping & storage temperature: -10°C~70°C
- Working environment: 0°C to 40°C, 10% 95% RH Non-condensation
- Wireless transmit range: 30M in the open air




- (1) Power indicator
- (2) Distribution network indicator
- (3) Heating indicator
- (4) Distribution network button

Long press the button for 3s to distribute the network.

(5) Boost function button

Press the button to switch heating mode or stop heating.



Installation


Flush Mounted













- Pry open the two covers (Red wireframe part)
- 1. Pry open the two covers on the back.
- 2. Connect the terminals in the correct way. Then mounting the fastening crimping bar screws.
- 3. Mounting screws. Buckle into the panel from top to bottom.
- 4. Tighten the screws at the bottom and complete.

Surface Mounted



1.Connect the terminals in the correct way.



2. Mounting the fastening crimping bar screws




3. Mounting screws. Buckle into the panel from top to bottom



4. Tighten the screws at the bottom and complete.

Wiring diagram



Imax:250VAC / 5(3)A

Link APP (Login)

Download:

Click App store or Android application market to download "Tuya Smart "app.

Registration and Login:

Click the "Register" to create account. Enter your account password to log in.



Link APP (Add devices)

Add gateway:

Tips: Turn on the Bluetooth and Wifi of your mobile phone.

1 Enter the "HOME" interface of the app, Click the "Add" .



wait a few seconds until the search progress is 100%.



2 Enter your wifi account and password, Click "Confirm".



4 Click "Done", it means the gateway added successfully.



* Tips Before binding the gateway, you need to power on the gateway.

When binding a gateway, the mobile phone and the gateway must connect to the same network.